

INSTRUCTION MANUAL FTHYL FTHER DETECTOR TUBE

No.107U

- ★ READ CAREFULLY THIS INSTRUCTION MANUAL AND THE INSTRUCTIONS OF THE ASPIRATING PUMP PRIOR TO USING THIS PRODUCT.
- ★ DO NOT DISCARD THIS INSTRUCTION MANUAL UNTIL ALL THE TUBES IN THIS BOX ARE USED UP

1. PERFORMANCE:

Measuring Range	: 20 - 400ppm
and Sampling Time	: 1.5 minutes
Number of pump stroke	: 1 (100mL)
Colour Change	: Pale yellow → Pale Blue
Detectable Limit	: 1ppm (1 pump stroke)
Operating temperature	: 10 - 40 °C (50-104°F) (Temperature correction is necessary.)
Aspirating Pump	: Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A

ACAUTION

- 1. DETECTOR TUBE CONTAINS REAGENTS.
- 2. DO NOT TOUCH THESE REAGENTS DIRECTLY ONCE TUBES ARE BROKEN. 3. KEEP THE TUBES OUT OF THE REACH OF CHILDREN.

- USE ONLY PUMP MODELS AP-20, AP-20S, 400B, AP-1, AP-1S OR 400A. OTHERWISE, CONSIDERABLE ERROR IN INDICATION MAY OCCUR.
- 2. BEFORE TESTING, CHECK THE ASPIRATING PUMP FOR LEAKS (REFER TO ITEM 8 INSPECTION OF ASPIRATING PUMP). ANY PUMPS SHOWING SIGNS OF LEAKAGE SHOULD BE CORRECTED BEFORE USE.
- 3. DO NOT USE THIS TUBE OUTSIDE THE STATED OPERATING TEMPERATURE RANGE.
- 4. STORE TUBES IN A COOL AND DARK PLACE (0-25 °C/32-77°F), AND USE BEFORE EXPIRATION DATE PRINTED ON TOP OF THE BOX.
- 5. PRIOR TO USE, READ CAREFULLY ITEM 9. USER RESPONSIBILITY.
- 6. READ THE CONCENTRATION IMMEDIATELY AFTER MEASUREMENT.

2. SAMPLING AND MEASUREMENT:




Fig.1

Break both ends of detector tube.

ACAUTION SAFETY GLASSES AND GLOVES SHOULD BE WORN TO PREVENT INJURY FROM SPLINTERING GLASS.

- 2 Insert the detector tube into aspirating pump securely as shown in Fig.1. (Arrow mark shall point to the pump.)
- Align the guide marks on the handle and stopper of the aspirating pump.
- 4 Pull the pump handle at full stroke until it locks and wait for 1.5 minutes or until the completion of sampling is confirmed with the flow indicator of the pump (See descriptions about the flow indicator in the instructions of the pump).
- ⑤ On completion of sampling, read the scale at the maximum point of the stained layer.

- SPECIAL NOTE: I. The scale is calibrated at 20 °C (68°F), 50 %R.H. and 1013hPa. Readings obtained in other circumstances should be corrected (REFER TO ITEM 3. CORRECTION FOR AMBIENT CONDITIONS).
 - II. When the maximum point of the stained layer is unclear or obliquely, read the scale at the centre between the longest and shortest points.

3 CORRECTION FOR AMBIENT CONDITIONS:

① Temperature; Correct the tube reading by following temperature correction table.

Temperature Correction Table						
Tube	Corrected Concentration (ppm)					
Readings	10 ℃	20 ℃	30 ℃	40 °C		
(ppm)	(50°F)	(68°F)	(86°F)	(104°F)		
400	640	400	290	230		
300	480	300	220	180		
200	320	200	150	120		
150	240	150	110	90		
100	160	100	80	60		
50	90	50	40	30		
20	40	20	20	10		

2 Humidity; No correction is necessary.

3 Atmospheric Pressure	

True concentration = Temperature corrected × concentration

1013 Atmospheric pressure (in hPa)

4. INTERFERENCES:

Alchols, Esters, Ketones or Aromatic hydrocarbons produce similar stains and give higher reading. Aromatic hydrocarbons change the whole reagent to pale brown and coexistence of then with Methyl ether give higher reading.

5. CHEMICAL REACTION IN THE DETECTOR TUBE:

 $C_2H_3OC_2H_3+Cr^{6+}+H_2SO_4 \rightarrow Cr^3$

6. DISPOSAL OF TUBE:

USED TUBES SHOULD BE DISPOSED CAREFULLY ACCORDING TO RELEVANT REGULATIONS, IF ANY.

7. HAZARDOUS AND DANGEROUS PROPERTIES OF ETHYL ETHER:

TLV-TWA.◆

400 ppm Explosive range in air : 1.9 - 48.4 %

◆ Threshold Limit Value established by the American Conference of Governmental Industrial Hygienists, 2004.

8. INSPECTION OF ASPIRATING PUMP:

Checking for leaks:

- (1) Insert sealed, unbroken detector tube into the pump.
- ② Align the guide marks on the shaft and stopper of the pump.
- 3 Pull the handle to full stroke and wait for 1 minute.
- 4 Unlock the handle and allow it to return slowly into the pump by holding the cylinder and handle securely.

ACAUTION HANDLE WILL TEND TO SNAP BACK INTO THE PUMP QUICKLY.

(5) If the handle returns completely to the original position, the performance is satisfactory. Otherwise, refer to maintenance procedure in the instruction manual to correct the leakage.

9. USER RESPONSIBILITY:

It is the sole responsibility of the user of this equipment to ensure that the equipment is operated, maintained, and repaired in strict accordance with these instructions and the instructions provided with each Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A aspirating pump, and that detector tubes are not used which are either beyond their expiration date or have a colour change different to that stated in the Performance specifications.

The Manufacturer and Manufacturer's Distributors shall not be otherwise liable for any incorrect measurement or any damages, whether damages result from negligence or otherwise.